

Solar Lamp

Problem	Solution
Unable to switch on Solar Lamp	<ul style="list-style-type: none">• Check if the battery is charged• Alternately keep the Solar Lamp in direct sunlight and check if the Solar Lamp indicates red light next to the LED. If not, after few hours try switching on the Solar Lamp and if the Bulb still does not glow, please check with your dealer.
Solar Lamp is not charging from the sun	<ul style="list-style-type: none">• Ensure that the Solar Lamp is kept under direct sunlight with the solar panel of the Solar Lamp facing the sun• Red light indicator will glow as soon as the Solar Lamp starts charging
Solar Lamp bulb is not bright	<ul style="list-style-type: none">• Make sure that the Solar Lamp is charged to its capacity• Low battery may give a lower light output• The Solar Lamp requires about 8 hrs of direct sunlight to get fully charged
Why does the Red light blink	<ul style="list-style-type: none">• The Solar panel is light sensitive and will indicate as if charging, but will not result in any charge to the battery until it is kept under direct sunlight
The Solar Lamp is taking too long to charge even in direct sunlight	<ul style="list-style-type: none">• Check if the solar panel is facing the sun throughout the day• Continuous direct sunlight is needed to charge within the specified time.• Check if the sunlight is blocked• Make sure that the solar panel is clean and dry• Check if there are any visible scratches or cracks on the solar panel